



**Yaskawa P7 Drive Program
for the 5 hp 230 volt Mixer**

ALL SETTINGS ARE AT DEFAULT EXCEPT FOR THE FOLLOWING

ADDRESS	SET TO	ALTERNATE SETTING	DESCRIPTION
A1-03	3330 (SET THIS CODE FIRST)	N/A	3 WIRE CONTROL
B1-03	1	N/A	COAST TO STOP
C1-01	2	N/A	ACCEL TIME
C1-02	3	N/A	DECEL TIME
E1-04	60	N/A	MAX FREQUENCY
E2-01	15	N/A	MOTOR FLA
L3-01	0	N/A	STALLP ACCEL SEL
L3-04	0	N/A	STALLP DECEL SEL
L3-06	100	N/A	STALL PREV RUN
L4-05	0	N/A	SIGNAL LOSS
O1-03	1	N/A	DISPLAY UNITS

Updated 6/30/08

**Yaskawa P7 Drive Program
for the 5 hp 460 volt Mixer**

ALL SETTINGS ARE AT DEFAULT EXCEPT FOR THE FOLLOWING

ADDRESS	SET TO	ALTERNATE SETTING	DESCRIPTION
A1-03	3330 (SET THIS CODE FIRST)	N/A	3 WIRE CONTROL
B1-03	1	N/A	COAST TO STOP
C1-01	2	N/A	ACCEL TIME
C1-02	3	N/A	DECEL TIME
E1-04	60	N/A	MAX FREQUENCY
E2-01	7.5	N/A	MOTOR FLA
L3-01	0	N/A	STALLP ACCEL SEL
L3-04	0	N/A	STALLP DECEL SEL
L3-06	100	N/A	STALL PREV RUN
L4-05	0	N/A	SIGNAL LOSS
O1-03	1	N/A	DISPLAY UNITS

Updated 6/30/08